


**Assembly instructions
LED Light Guide Set
NM-AUD-001
zr-lgs-001**





The smart difference.



1. Press in lens(es)

Using moderate pressure, press the lense(es) into the designated hole(s) in the Rack Mount Kit.






2. Loosely pre-assemble the light pipe holder

Fasten the light pipe holder loosely to the Rack Mount Kit with the fastening screws (included in the scope of supply).

3. Loosely mount the flexible light pipe

Fasten the light pipe(s) loosely to the light pipe holder with the fixing screw(s) (included in the scope of supply).



4. Fasten the light pipe holder and the flexible light pipe

Adjust the light pipe(s) for optimal illumination at the front of the Rack Mount Kit and tighten the screws.